



Anybus® Wireless Bridge

Ethernet–Bluetooth®

USER MANUAL

HMSI-27-206 2.3 ENGLISH



Important User Information

Liability

Every care has been taken in the preparation of this document. Please inform HMS Industrial Networks AB of any inaccuracies or omissions. The data and illustrations found in this document are not binding. We, HMS Industrial Networks AB, reserve the right to modify our products in line with our policy of continuous product development. The information in this document is subject to change without notice and should not be considered as a commitment by HMS Industrial Networks AB. HMS Industrial Networks AB assumes no responsibility for any errors that may appear in this document.

There are many applications of this product. Those responsible for the use of this device must ensure that all the necessary steps have been taken to verify that the applications meet all performance and safety requirements including any applicable laws, regulations, codes, and standards.

HMS Industrial Networks AB will under no circumstances assume liability or responsibility for any problems that may arise as a result from the use of undocumented features, timing, or functional side effects found outside the documented scope of this product. The effects caused by any direct or indirect use of such aspects of the product are undefined, and may include e.g. compatibility issues and stability issues.

The examples and illustrations in this document are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular implementation, HMS Industrial Networks AB cannot assume responsibility for actual use based on these examples and illustrations.

Intellectual Property Rights

HMS Industrial Networks AB has intellectual property rights relating to technology embodied in the product described in this document. These intellectual property rights may include patents and pending patent applications in the USA and other countries.

Trademark Acknowledgements

Anybus® is a registered trademark of HMS Industrial Networks AB. All other trademarks are the property of their respective holders.

Table of Contents

Page

1	About This Document	3
1.1	Document history	3
1.2	Conventions	4
2	Product Description	5
2.1	LED Indicators	5
3	Installation	6
4	Startup and Configuration	7
4.1	Options for Device Configuration	7
4.2	Factory Reset	7
4.3	SMART Configuration	8
4.4	Web Configuration	9
5	Configuration Examples.....	16
5.1	Example 1: Simple Ethernet Bridge	16
5.2	Example 2: Bluetooth Roaming	17
5.3	Example 3: PC Connecting to Wired Network via Bluetooth.....	18
A	Wireless Technology Basics	19
B	Technical Data.....	20
B.1	Technical Specifications	20
B.2	Internal Antenna Characteristics	21
B.3	Regulatory Compliance	22
B.4	Licenses	24

This page intentionally left blank

1 About This Document

This manual describes how to install and configure Anybus Wireless Bridge Ethernet to Bluetooth.

For additional related documentation and file downloads, please visit the support website at www.anybus.com/support.

1.1 Document history

Summary of recent changes

Change	Where (section no.)
Added info about Telnet access	4.1
Added explanation of Bluetooth EDR	4.4.1
Updated configuration examples	5
Added antenna characteristics	B.2
Fixed typos etc.	—

Revision list

Version	Date	Author	Description
1.00	2011-03-22	KaD	First released version
1.10	2012-04-03	KaD	Converted to FrameMaker, minor updates and corrections
1.20	2013-10-09	SDa	Added safety warnings
2.0	2016-05-01	ThN	Major rewrite, new structure and layout
2.1	2016-06-15	ThN	Removed Bluetooth LE Updated compliance information
2.2	2016-07-12	ThN	Minor update
2.3	2016-07-14	ThN	Minor update

1.2 Conventions

Unordered (bulleted) lists are used for:

- Itemized information
- Instructions that can be carried out in any order

Ordered (numbered or alphabetized) lists are used for instructions that must be carried out in sequence:

1. First do this,
2. Then open this dialog, and
 - a. set this option...
 - b. ...and then this one.

Bold typeface indicates interactive parts such as connectors and switches on the hardware, or menus and buttons in a graphical user interface.

Monospaced text is used to indicate program code and other kinds of data input/output such as configuration scripts.

This is a cross-reference within this document: [Conventions, p. 4](#)

This is an external link (URL): www.hms-networks.com



This is additional information which may facilitate installation and/or operation.



This instruction must be followed to avoid a risk of reduced functionality and/or damage to the equipment, or to avoid a network security risk.



Caution

This instruction must be followed to avoid a risk of personal injury.



WARNING

This instruction must be followed to avoid a risk of death or serious injury.

2 Product Description

2.1 LED Indicators

2.1.1 Status LED Indicators




Fig. 1 Status LED indicators

LED Indication		Meaning
PWR	OFF	No power or no application running
	Steady Green	Unit has power and application is running
)))	OFF	No wireless activity
	Steady Blue	A wireless connection has been established
	Flashing Blue	Wireless data activity
	Steady Purple	Attempting to establish a wireless connection
	Steady Red	Wireless connection error
LAN	OFF	No Ethernet connection
	Steady Yellow	Ethernet link is present
	Flashing Yellow	Ethernet data activity

2.1.2 A-B-C-D LED Indicators




Fig. 2 A-B-C-D LED indicators

The **A-B-C-D** LEDs are multi-functional. On a client operating in PANU mode they indicate the wireless link quality: 4 LEDs lit = excellent signal. On the Access Point model they instead indicate the number of connected clients.

The LEDs are also used when selecting a SMART configuration mode.

3 Installation



Caution

This equipment emits RF energy in the ISM (Industrial, Scientific, Medical) band. Make sure that all medical devices used in proximity to this device meet appropriate susceptibility specifications for this type of RF energy.



This product contains parts that can be damaged by electrostatic discharge (ESD). Use ESD protective measures to avoid equipment damage.

Make sure that you have all the necessary information about the capabilities and restrictions of your local network environment before installing the Anybus Wireless Bridge. Contact your network administrator if in doubt.

For optimal reception between units they should be oriented front-to-front with the line of sight between them clear of obstructions. A minimum distance of 50 cm between the devices should be observed to avoid interference.

See also [Wireless Technology Basics, p. 19](#) and [Internal Antenna Characteristics, p. 21](#).




Fig. 3 Installation drawing

4 Startup and Configuration

4.1 Options for Device Configuration

SMART Configuration

Basic use cases can be set up quickly using the **MODE** button and the **A-B-C-D** LEDs to select one of the SMART configuration modes.

See [SMART Configuration, p. 8](#).

Web Configuration

The built-in web server gives access to status information and configuration settings via a graphical user interface.

See [Web Configuration, p. 9](#).

AT Commands

Advanced configuration can be carried out by issuing AT (Hayes) commands in the **Advanced** section of the web interface or using a Telnet connection to the Wireless Bridge on port 8080.

A list of supported AT commands can be found at www.anybus.com/support.

4.2 Factory Reset

Anybus Wireless Bridge can be reset to the factory default settings in one of the following ways:

- Keeping the **MODE** button pressed while the unit is starting up
- Executing SMART Mode 2 (see [SMART Configuration, p. 8](#))
- Issuing the AT command **AT&F** (see [Settings – Advanced View, p. 15](#))

Factory Default Settings (IP Configuration)

IP Assignment:	Static
IP Address:	192.168.0.98
Subnet Mask:	255.255.0.0
Default Gateway:	192.168.0.98
Web configuration password:	(no password)

See [Web Configuration, p. 9](#) for information about the default settings of all parameters.



Do not reset the Anybus Wireless Bridge while a firmware update is in progress.



As the default password setting is empty (no password), setting a secure password when first configuring the unit is strongly recommended.

4.3 SMART Configuration




Fig. 4 **MODE** button and LED indicators

1. Power on the Wireless Bridge, then immediately press and release **MODE**.
2. Press **MODE** repeatedly to cycle through the configuration modes until the desired mode is indicated by the LED combination.
3. Press and hold **MODE** until the LEDs go out or blink, then release the button. The unit will restart with the selected configuration.



If the unit is not restarted within 20 seconds of selecting a configuration mode it will exit SMART configuration and return to the previous settings.

MODE	Operation	Description	LED			
			A	B	C	D
1	—	Enable DHCP server	•			
2	—	Reset to factory defaults		•		
3	—	Reset IP settings	•	•		
4	PANU-PANU	Wait for auto configuration			•	
5	PANU-PANU	Initiate auto configuration	•		•	
6	PANU-PANU	Initiate auto configuration (PROFINET priority)		•	•	
7	PANU-NAP	Initiate auto configuration	•	•	•	
8	PANU-PANU + EDR	Wait for auto configuration				•
9	PANU-PANU + EDR	Initiate auto configuration (PROFINET priority)	•			•
10	NAP-PANU	Wait for auto configuration		•		•
11–15	(reserved for future use)					




SMART modes 4–9 cannot be used in the Access Point model.

PANU	PAN User mode – the device can connect to another single Bluetooth device or to a Bluetooth access point.
NAP	Network Access Point mode – the device operates as a Bluetooth access point.
EDR	Enhanced Data Rates (not supported by all Bluetooth devices)
Enable DHCP Server	Activates a built-in DHCP server which makes it possible to access the Wireless Bridge without manually configuring the IP address of the connecting computer. The computer must be set up for DHCP and be connected directly to the unit, not through a network. The DHCP server will stay enabled until the unit is restarted.
PROFINET priority	PROFINET network traffic will be prioritized.

4.4 Web Configuration

The web configuration interface can be accessed by entering the IP address of the Anybus Wireless Bridge in any web browser that supports HTML5. The computer used for configuration must be in the same subnet as the Wireless Bridge.

 The default IP address is 192.168.0.98.

The initial page (Info page) shows the status and basic settings of the Wireless Bridge. The colors of the **LAN Status** and **Bluetooth Status** entries correspond to the LED indicators.

Click on **Update Status** to refresh the values once, or on **Auto Update** to make the values refresh every second.

To access the configuration page, click on **Settings** and enter the password to login.



The default password setting is empty (no password). Setting a secure password when first configuring the unit is strongly recommended.




Fig. 5 Status page




Fig. 6 Login page

4.4.1 Settings – Standard View

Top Menu

Info Logout Advanced view

Anybus Wireless Bridge ETH-BT
Order No. 023140

Load Configuration
Browse... No file selected. Set & Reboot

Network

IP Configuration
IP Address 192.168.0.98
Subnet Mask 255.255.0.0
Default Gateway 192.168.0.98
IP Assignment Static Set & Reboot

ProfiNet
ProfiNet Prioritization Off
ProfiSafe Off Set

Bluetooth

General
Operation Mode PANU (client)
Max. Transmit Power +10 dBm (Max)
Data Policy EDR Set & Reboot

Security
Security Mode On
Passkey 0x431259e6e15d11f079 Set

WLAN Coexistence
Low Emission Mode Off
Exclude WLAN Channel None Set

Connection
Connection Scheme Connect to MAC
Connect To PANU
MAC Address Set

SMART Mode Configuration

SMART Modes
4 - Wait for Automatic Configuration PANU-PANU
Execute

Service

Change Password
New Password
Confirm Password Set

System Identification
Device Name wireless-bridge
Description Bluetooth Ethernet Port Adapter
Physical Location unknown
Contact unknown
General Data Set

Miscellaneous
Event Subscriber Off Set

Export Configuration
Export current configuration Export configuration

Bottom Menu

Reload Settings Write all Reboot

Fig. 7 Standard view

Top Menu

Info	Return to the Info page but stay logged in.
Logout	Return to the Info page and log out.
Advanced view	Open the Advanced view (see Settings – Advanced View, p. 15).

Load Configuration

Browse	Select a saved configuration file.
Set & Reboot	Apply the configuration and reboot.

Bottom Menu

Reload Settings	Cancel all changes and reload the current configuration.
Write All	Apply all changed settings to the Anybus Wireless Bridge. This has the same function as clicking on Set in each of the different settings sections.
Reboot	Restart the Anybus Wireless Bridge (without applying changes).

Network – IP Configuration

IP Address	The IP address of the Anybus Wireless Bridge. Default: 192.168.0.98
Subnet Mask	Subnet mask. Default: 255.255.0.0
Default Gateway	IP address of the transition point to other network segments. Must also be set when DHCP addressing is used. Default: 192.168.0.98
IP Assignment	Static (default): The unit is assigned the IP address set above. DHCP : IP configuration settings are retrieved from a DHCP server. Static & DHCP Server : The unit is assigned the IP address set in the IP Address field and operates as DHCP server for devices connected to the LAN port.
Set & Reboot	Apply the changes and reboot.

Network – PROFINET

PROFINET Prioritization	Enable/disable prioritization for PROFINET
PROFIsafe	Enable/disable PROFIsafe functionality
Set	Apply the changes (no reboot required).

Bluetooth – General

Operation Mode	PANU : Client within a Personal Area Network (PAN) – can also be used for point-to-point connections. NAP : Network Access Point (“master” in a PAN) – up to seven connections can be managed.
Max. Transmit Power	Selection of the maximum transmission power (not including antenna gain) <i>Note: Bluetooth automatically reduces the actual transmission power to the level required for the current connection. Manually reducing the transmission power is only recommended for range limitation.</i>
Data Policy	Optimizing the data transmission method. High Speed (default): All packet sizes (DM and DH) are selected automatically. The system automatically selects the most suitable packet size for the Ethernet packet. Short Delay : All DM packet sizes and QoS prioritizing are used, resulting in the lowest possible latency. High Range : Only DM1 packets can be used. Transmission will be slower but more stable, particularly in the event of long distances and/or demanding environments. EDR : Optimum transmission as long as the Bluetooth 2.1+EDR standard is supported by both sides. EDR (Enhanced Data Rate) is a faster PSK modulation scheme which supports up to 2 Mbit/s gross air bit rate.
Set & Reboot	Apply the changes and reboot.

Bluetooth – Security


Security Mode	<p>Activate/deactivate encryption and authentication.</p> <p>ON (default): Encryption and authentication must be used. (GAP security mode 3 with encryption)</p> <p>OFF: No additional security mechanisms. Each device can log in without having to enter a passkey. (GAP security mode 1 without encryption)</p>
Passkey	Key to be entered for authentication during connection establishment. Make sure you choose a unique and secure key.
Set	Apply the changes (no reboot required).

Bluetooth – WLAN Coexistence

Low Emission Mode	<p>OFF (default): LEM 0 – The behavior corresponds to that of the Bluetooth standard. Enables operation with standard-compliant Bluetooth devices.</p> <p>ON: LEM 3 – The device has less impact on the wireless channel during connection establishment. This mode is particularly recommended for parallel operation with WLAN networks.</p> <p><i>Note: Both communication partners must operate in the same LEM mode. Otherwise, connection establishment can take a very long time.</i></p>
Exclude WLAN Channel	<p>Select WLAN channels that should not be used by the Bluetooth system (WLAN black channel list).</p> <p>A maximum of three WLAN channels can be hidden without restricting the function of the Bluetooth system. By excluding WLAN channels, the available bandwidth will be reduced and thus the number of Bluetooth systems that can be operated in parallel.</p> <p>WLAN channels should only be hidden if they are actually required for high-availability WLAN systems.</p>
Set	Apply the changes (no reboot required).


Bluetooth – Connection

Connection Scheme (PANU mode)	<p>Connect to MAC: A direct connection is established to another device with a specified MAC address.</p> <p>Connect to Name (Best RSSI): Searches for Bluetooth devices with a specified name. Connection will then be established with the device that has the highest receive field strength.</p> <p>Connect to Name (Fast): Establishes a connection to the first device responding with the specified name. This mode is faster but does not always ensure optimum connection.</p> <p>Connect to Name (P2P only): Attempts to establish a connection with the first responding device. If the device name does not match the specified, the connection attempt will be aborted.</p> <p>Connections can be established very quickly with this mode, but only if there are no other visible devices.</p>
Connection Scheme (NAP mode)	<p>Wait (MAC): Other devices can connect to the access point quickly based on its MAC address.</p> <p>Wait (Name): The access point waits for connection requests based on the name entered in the Local Name field.</p>
Connect To (PANU mode)	<p>Select PANU when connecting to another Bluetooth client device.</p> <p>Select NAP when connecting to a Bluetooth access point.</p>
MAC Address/Name (PANU mode)	<p>The MAC address or Bluetooth device name to connect to. Click on Scan to scan for devices, or enter the MAC address or device name manually.</p>
Local Name (NAP mode)	<p>The name used to identify the Wireless Bridge to other Bluetooth devices when operating in access point mode.</p>
Set	<p>Apply the changes (no reboot required).</p>

 *To establish a connection based on name, a device must be able to respond to a scan (visible). A device is only visible as long as the maximum number of connections has not been reached.*

Bluetooth – Roaming (PANU mode)

Link Sensitivity	<p>Long Range: Maintain the current connection as long as possible.</p> <p>Medium: Default setting.</p> <p>High Speed: Switch to a device with higher RSSI as soon as possible.</p> <p>Using the same setting for both the roaming and the network devices is recommended.</p>
-------------------------	---

 *A time limit for changing from one connection to another when roaming cannot be ensured in Bluetooth networks. Roaming times will increase with higher network utilization.*

SMART Mode Configuration

SMART Modes	See SMART Configuration, p. 8 .
Execute	Apply the selected SMART configuration mode and reboot.

Service – Change Password

New Password	Enter a new password for the web configuration interface.
Confirm Password	Enter the new password again.
Set	Confirm the new password (it will be required on the next login attempt).

Service – System Identification

Device Name	A name for the device.
Description	A short description of the device.
Physical Location	The location of installation.
Device Contact	Contact person (including e-mail, phone number, etc.).
General Data	Additional information about the device.
Set	Apply the changes (no reboot required).

Miscellaneous

Event Subscriber	Activate sending of system events via TCP or Syslog.
Value	Select which values to send: Receive quality (RSSI), Connection, or both
IP Address (Syslog only)	The IP address of the Syslog server.
Set	Apply the changes (no reboot required).

Export Configuration

Export configuration	Save the current configuration settings as AT commands in a text file.
-----------------------------	--

4.4.2 Settings – Advanced View

The screenshot displays the 'Advanced View' configuration interface. At the top, the 'AT Commands' section includes a text box for entering commands and a 'Send' button. Below this, the 'AT Response' section contains a scrollable log window showing a sequence of AT commands and their responses, such as 'AT*AMPID?', '*AMPID:3060', 'OK', 'AT*AILVI?', '*AILVI:"HMS", "2.5.0 RC1 [15:02:34,Oct 28 2015]", "3.1.7", "OK', 'AT*AMPID?', '*AMPID:3060', 'OK', 'AT*AILVI?', '*AILVI:"HMS", "2.5.0 RC1 [15:02:34,Oct 28 2015]", "3.1.7", "OK', 'AT*ANIP?', '*ANIP:192.168.0.99,255.255.0.0,192.168.0.98', and 'OK'. A 'Clear' button is positioned below the log window. The bottom section, 'Firmware update from TFTP Server', includes input fields for 'Server IP Address' and 'File name', followed by an 'Update' button.

Fig. 8 Advanced view

AT Commands

AT Commands Enter AT commands into the field, then click on **Set** to upload them to the Wireless Bridge.

AT Response Shows a log of the latest AT commands and their responses.

Clear Clears the log window.

Firmware update from TFTP Server

Server IP Address Enter the IP address of the TFTP server that provides the firmware file.

File name Enter the filename of the firmware file.

Update Click on **Update** to upload the firmware to the Wireless Bridge.
Make sure that TFTP traffic (UDP port 69) is not blocked by a firewall.



Do not reset the Wireless Bridge during a firmware update.

5 Configuration Examples

The following configuration examples require a basic understanding of how to install and power up Anybus Wireless Bridge and how to access and use SMART configuration modes. Read sections [Product Description](#) and [Startup and Configuration](#) before you continue.

- All the examples start out from the factory default settings.
- Settings not mentioned in the examples should normally be left at their default values.
- The Ethernet networks in the examples use static IP addressing within the default subnet range of the Wireless Bridge.
- The computer used for web configuration must be in the same subnet as the Wireless Bridge being configured.

5.1 Example 1: Simple Ethernet Bridge




Fig. 9 Two Anybus Wireless Bridges used as an Ethernet bridge

This example describes two Wireless Bridges in PANU mode connecting two Ethernet network segments.

1. Reset both Wireless Bridges to the factory default settings.
2. On the first Wireless Bridge, activate SMART mode 4 (LED C).
The LED will blink while the unit is waiting for a connection.



3. On the second Wireless Bridge, activate SMART mode 5 (LED A+C).
The LEDs will blink until the units have connected.



4. When the Wireless Bridges have connected successfully the))) LED on both units will show a steady blue light. The first unit will have IP address 192.168.0.98 and the second 192.168.0.99.

5.2 Example 2: Bluetooth Roaming



Fig. 10 Roaming between multiple Wireless Bridges

This example describes a Wireless Bridge roaming between two or more Wireless Bridges connected to a local network.

1. Reset all the Wireless Bridges to the factory default settings.
2. Open the web interface of the **roaming** Wireless Bridge and set up the following configuration:

Parameter	Value
Bluetooth - Connection	
Connection Scheme	Connect to name (Best RSSI)
Connect To	PANU
Name	The Bluetooth device name for the other Wireless Bridges. Click on Scan to detect the other Wireless Bridges, or set the name manually. (Default: Wireless Bridge ETH-BT)

3. Click on the **Set** button next to the **Name** field to save the configuration. The device will immediately try to connect to the Wireless Bridge that has the strongest signal (RSSI) of those with a matching device name.

5.3 Example 3: PC Connecting to Wired Network via Bluetooth






Fig. 11 PC connecting to a wired network via a Bluetooth Wireless Bridge

This configuration example describes a computer using Bluetooth to connect to an Ethernet network via a Wireless Bridge.



The example shows how to connect to a Bluetooth device in Windows 7. Please refer to the documentation for the operating system of your computer on how to set up Bluetooth networking.

1. Reset the Wireless Bridge to the factory default settings.
2. Open the network settings on the computer and connect to the Bluetooth PANU device with the name of the Wireless Bridge (Wireless Bridge ETH-BT).



A Wireless Technology Basics

Wireless technology is based on the propagation and reception of electromagnetic waves. These waves respond in different ways in terms of propagation, dispersion, diffraction and reflection depending on their frequency and the medium in which they are travelling.

To enable communication there should optimally be an unobstructed line of sight between the antennas of the devices. However, the so called *Fresnel Zones* should also be kept clear from obstacles, as radio waves reflected from objects within these zones may reach the receiver out of phase, reducing the strength of the original signal (also known as phase cancelling).

Fresnel zones can be thought of as ellipsoid three-dimensional shapes between two wireless devices. The size and shape of the zones depend on the distance between the devices and on the signal wave length. As a rule of thumb, at least 60 % of the first (innermost) Fresnel zone must be free of obstacles to maintain good reception.




Fig. 12 Fresnel zones

Area to keep clear of obstacles (first Fresnel zone)

Distance (d)	Fresnel zone radius (r)	
	2.4 GHz (WLAN or Bluetooth)	5 GHz (WLAN)
100 m	1.7 m	1.2 m
200 m	2.5 m	1.7 m
300 m	3.0 m	2.1 m
400 m	3.5 m	2.4 m

The wireless signal may be adequate even if there are obstacles within the Fresnel zones, as it always depends on the number and size of the obstacles and where they are located. This is especially true indoors, where reflections on metal objects may actually help the propagation of radio waves. To reduce interference and phase cancelling, the range may also need to be limited by reducing the transmission power. For determining the optimal configuration and placement of wireless devices it is therefore recommended to use a wireless signal analysis tool.

B Technical Data

B.1 Technical Specifications

Model	Ethernet Bridge	Access Point
Order code	023140	024130
Dimensions (L x W x H)	91 x 66 x 36.2 mm	
Weight	120 g	130 g
Operating temperature	-30 to +65 °C	
Storage Temperature	-40 to +85 °C	
Humidity	RH 5–90 % non-condensing	
Input voltage	9–30 V DC (SELV)	
Power consumption	1.8 W (typical) — see also Typical current consumption at 24 VDC	
Enclosure material	Plastic	
Mechanical rating	IP65	
Power connector	M12	
Ethernet connector	M12	
Mounting	Screw holes for wall mounting	
Antenna	Internal	External (RPSMA)
Transmission power	13 dBm max.	20 dBm max.
Receiver sensitivity	-92 dBm max.	
Maximum range	300 m	
Maximum throughput	1 Mbps	
Ethernet interface	10/100BASE-T with automatic MDI/MDIX cross-over	
Ethernet protocols	IP, TCP, UDP, LLDP, HTTP, ARP, DHCP client/server, DNS support, SNMP user management and access control	
Default IP address	192.168.0.98	
Bluetooth specification	Bluetooth 4.0 Basic Rate/EDR Core Configuration	
Bluetooth profiles	Generic Attribute Profile (GATT), Personal Area Networking Profile (PAN), PANU and NAP roles (one connection)	
Bluetooth security	Simple pairing	
Number of clients	1	7
Wireless certifications	Europe (ETSI, R&TTE), USA (FCC/CFR 47 part 15 unlicensed modular transmitter approval), Canada (IC, RSS), Japan (MIC)	
Environm. certifications	CE, cULus, Haz.Loc Class 1 Div. 2	

Typical current consumption at 24 VDC

Operation	Mean (mA)	Max (mA)
Startup	—	56.1
Idle	44.0	45.5
Idle, Ethernet	54.0	56.0
Idle + 4 x Mode LEDs	54.3	56.1
Connecting	60.1	60.6
Connected, Data	48.3	48.4
Connected, Data, Ethernet	54.2	54.4
Connected, Data, Ethernet, 4 x Mode LEDs	57.8	58.9

B.2 Internal Antenna Characteristics




Fig. 13 Longitudinal axis




Fig. 14 Transverse axis

B.3 Regulatory Compliance

EMC Compliance (CE)



The Anybus Wireless Bridge models 023140-B and 024130-B are in compliance with the RED Directive 2014/53/EU through conformance with the following standards:

Effective use of frequency spectrum

EN 300 328 V1.9.1 (2015-02)

EN 301 893 V1.8.1 (2015-03)

Safety

EN 62479:2010

EN 60950-1:2006 + A11:2009 + A1:2010 + A12:2011
+ A2:2013

IEC 60950-1:2005 + A1:2009 + A2:2013

EMC

EN 301 489-1 V1.9.2 (2011-09)

EN 301 489-17 V2.2.1 (2012-09)

EN 61000-6-2:2005

EN 61000-6-3:2007 + A1:2011

The Declaration of Conformity is available at www.anybus.com/support.

Disposal and Recycling



You must dispose of this product properly according to local laws and regulations. Because this product contains electronic components, it must be disposed of separately from household waste. When this product reaches its end of life, contact local authorities to learn about disposal and recycling options, or simply drop it off at your local HMS office or return it to HMS.

For more information, see www.hms-networks.com.

UL Certification



LISTED 67AM

This equipment is suitable only for use in Class I, Division 2, Groups A, B, C and D OR non-hazardous locations only. Combinations of equipment in your system are subject to investigation by the local Authority Having Jurisdiction at the time of installation.



WARNING

EXPLOSION HAZARD - SUBSTITUTION OF ANY COMPONENTS MAY IMPAIR SUITABILITY FOR CLASS I, DIVISION 2.

EXPLOSION HAZARD - DO NOT DISCONNECT EQUIPMENT UNLESS POWER HAS BEEN SWITCHED OFF OR THE AREA IS KNOWN TO BE NONHAZARDOUS.



AVERTISSEMENT

RISQUE D'EXPLOSION – LE REMPLACEMENT DE TOUT COMPOSANTS INVALIDE LA CERTIFICATION CLASS I, DIVISION 2.

RISQUE D'EXPLOSION – NE PAS DÉCONNECTER L'ÉQUIPEMENT TANT QUE L'ALIMENTATION EST TOUJOURS PRÉSENTE OU QUE LE PRODUIT EST TOUJOURS EN ZONE EXPLOSIVE ACTIVE.

FCC Compliance Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.



This equipment contains FCC ID: **PVH0946**



Any changes or modifications not explicitly approved by HMS Industrial Networks AB could cause the module to cease to comply with FCC rules part 15, and thus void the user's authority to operate the equipment.

Industry Canada Statement

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation

Cet équipement est conforme aux limites d'exposition de rayonnement d'IC RSS-102 déterminées pour un environnement non contrôlé. Cet équipement devrait être installé et actionné avec la distance minimum 20 cm entre le radiateur et votre corps.

Son utilisation est soumise aux deux conditions suivantes:

1. Cet appareil ne doit pas causer d'interférences et
2. il doit accepter toutes interférences reçues, y compris celles susceptibles d'avoir des effets indésirables sur son fonctionnement.

This equipment contains IC ID: **5325A-0946**

Japan Radio Equipment Compliance (MIC)

Contains MIC ID: R 204-210003



R 204-210003

B.4 Licenses

This product contains software under the following licenses:

Copyright (c) 2001–2004 Swedish Institute of Computer Science. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistribution of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistribution in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The name of the author may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This file is part of the lwIP TCP/IP stack.

Author: Adam Dunkels adam@sics.se

This page intentionally left blank

